

Configuring an Enroll & Delete Card in BioStar

Create an Enroll/Delete Card

To create an enroll card or delete card, click **Device**, select the reader you wish to attach the cards to, then select **Command Card** from the horizontal tab menu.

Under this tab, click on the drop menu beside **Command Type**, specify either 'Enroll Card' or 'Delete Card', and then click **Read Card**.

Card ID	Command
010-2542	Enroll Card

Buttons: Delete, Delete All, Read Card, Add

Form fields: Card ID (0 - 0), Command Type (Enroll Card, Enroll Card, Delete Card, Delete All Card)

Bottom buttons: Add, Modify, Delete, Apply to Others, Apply

The reader will prompt you to place a card – either with a flashing yellow LED light or an on-screen message. While the reader is looking for input, place your card to the device until the Card ID numbers fill out.

Click **Apply** and the Enroll Card will be added.

Card ID	Command
10-2544	Delete Card
10-2543	Enroll Card

Card ID: 0 - 0

Command Type: Enroll Card

Need Authentication by Administrator

Enrolling a New User

To enroll a user with the enroll card, present the Enroll Card to the reader. Once the reader reacts, it will prompt the new user to:

1. Scan the new card (if using card + fingerprint)
2. Place a finger
3. Place the same finger a second time

In between each step the reader will output a positive or negative response – ex: a green LED light for success, and a red light for failure. If the enrollment process fails (flashes red), ensure your operation mode is set correctly and retry the process above.